

IP CAM provides three types of video stream for you view, please refer to the information below:

1. 3gpp stream (mobile phone / PDA): rtsp://IP address/3gpp
2. MPEG-4 stream (PC): rtsp:// IP address /mp4
3. MJPEG stream (PC): rtsp:// IP address /jpeg

The item 1, you just follow the format (fill in the IP address) then you can see the image of IP CAM, but you should not saw video stream of IP CAM after you follow the items 2 and 3 format. Because in RTSP URL item, you can configure the name by you want, but not use "mp4" or "jpeg". By default, it is "play1.sdp" and "play2.sdp". Therefore, if you want to see it, please key in the format of "rtsp://xxx.xxx.xxx.xxx/play1.sdp", the last part of the URL need to be same as what you configured. Please check the attached file for the detailed information.