

On DES-3526/50, each block can configure 50 flow meter rules. For example:

DES-3526:

block 1 (Fast Ethernet port 1~8): 50 flow meter rules
block 2 (Fast Ethernetport 9~16): 50 flow meter rules
block 3 (Fast Ethernetport 17~24): 50 flow meter rules
block 4 (Giga combo port 25): 50 flow meter rules
block 5 (Giga combo port 26): 50 flow meter rules

In DES-3526, there are 5 block, so it supports up to 250 flow meter rules.

DES3550:

block 1 (Fast Ethernet port 1~8): 50 flow meter rules
block 2 (Fast Ethernetport 9~16): 50 flow meter rules
block 3 (Fast Ethernetport 17~24): 50 flow meter rules
block 4 (Fast Ethernetport 25~32): 50 flow meter rules
block 5 (Fast Ethernetport 33~40): 50 flow meter rules
block 6 (Fast Ethernetport 41~49): 50 flow meter rules
block 7 (Giga combo port 49): 50 flow meter rules
block 8 (Giga combo port 50): 50 flow meter rules

In DES-3550, there are 8 block, so it supports up to 400 flow meter rules.