



# DGS-3600 Firmware information

## DGS3627G-L2MGMT-MIB




Object name	swDevInfoFirmwareVersion
Object ID	1.3.6.1.4.1.171.11.70.8.2.1.1.5
Module	DGS3627G-L2MGMT-MIB
Base syntax	Octet String
Composed syntax	DisplayString
Access	Read-Only
Status	Current
Value list	1 : 0..255
Parent node	swL2DevInfo
First child	None
Description	Boot firmware Version.

## DGS3627-L2MGMT-MIB




Object name	swDevInfoFirmwareVersion
Object ID	1.3.6.1.4.1.171.11.70.6.2.1.1.5
Module	DGS3627-L2MGMT-MIB
Base syntax	Octet String
Composed syntax	DisplayString
Access	Read-Only
Status	Current
Value list	1 : 0..255
Parent node	swL2DevInfo
First child	None
Description	Boot firmware Version.

## DGS3612-L2MGMT-MIB: i




Object name	swDevInfoFirmwareVersion
Object ID	1.3.6.1.4.1.171.11.70.10.2.1.1.5
Module	DGS3612-L2MGMT-MIB
Base syntax	Octet String
Composed syntax	DisplayString
Access	Read-Only
Status	Current
Value list	1 : 0..255
Parent node	swL2DevInfo
First child	None
Description	Boot firmware Version.

### DGS3612G-L2MGMT-MIB:



Object name	swDevInfoFirm wareVersion
Object ID	1.3.6.1.4.1.171.11.70.9.2.1.1.5
Module	DGS3612G-L2MGMT-MIB
Base syntax	Octet String
Composed syntax	DisplayString
Access	Read-Only
Status	Current
Value list	1 : 0..255
Parent node	swL2DevInfo
First child	None
Description	Boot firm ware Version.

### DGS3650-L2MGMT-MIB:



Object name	swDevInfoFirm wareVersion
Object ID	1.3.6.1.4.1.171.11.70.5.2.1.1.5
Module	DGS3650-L2MGMT-MIB
Base syntax	Octet String
Composed syntax	DisplayString
Access	Read-Only
Status	Current
Value list	1 : 0..255
Parent node	swL2DevInfo
First child	None
Description	Boot firm ware Version.