How to set up the DDNS on DSR series

[Topology]:

DSR-500N WAN1(PPPoE)------------------D-Link DDNS

[Configuration]:

1. Setup the WAN1 interface to use the PPPoE

2. Under the **TOOLS**-> **Dynamic DNS**.

3. You have to specify the following information:

3a.Select the Dynamic DNS service: choose **dlinkdns**.

3b.Host and Domain Name:xxxxx.dlinkddns.com.

3c.Username:xxxxxx

3d.Password:xxxxxx

[Testing procedure]:

1. Make sure the IP address you get from PPPoE can correctly display in D-Link DDNS website

2. Disable or unplug the WAN1 interface and to get the new IP address.
3. After certain time and we can see the IP will change automatically.