Use free SMTP Server

Example:

E-Mai box	SMTP Server
@126.com	Smtp.126.com

Account1:test_Dview@126.com   Password: 123456
**Account2:** test_Dview2@126.com   Password: 123456
We use Account1 as sender to send email
Steps:
1、 Click the "Mail Server Config" button
2、 Fill them as following:

3、 Click "Test" button to test whether Email Configuration is ok. If it is no problem, it will give user as following message. And you can go to test_Dview@126.com email box, you will see one letter named "D-View Test Mail" which send by test_Dview

4、 Click the "OK" button
5、 Choose Device Name
6、 Choose Event Type
7、 Fill the Email user who you want to send.

After the configuration, if D-View receives the Device Authentication Fail trap, it will send this trap to test_Dview2@126.com.

1、D-View receive four time about this trap

2、And you can go to test_Dview2@126.com email box,you will receive four letter about this.

D-View Event

test::Net-172.18.190.0　Dev-172.18.190.29 Device Authentication Fail